

## FARO COLLECTION INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

### Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Pole
- Drapery rings
- Mounting brackets with Allen key
- Finials

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

### Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure
- Hacksaw (optional)

### Installing Your Faro Drapery Hardware:

You are now ready to install your hardware.

#### 1. Measure

Poles are pre-cut to your specified size. Measure the area you are covering and cut down pole if needed with hacksaw.

#### 2. Mark

Mark the height you would like the top of drapery pole to be installed. Note: The top of the drapery will hang down approx. 2" from the top of the pole.

#### 3. Mount

Measure the width of the pole. Mark the placement of the two end brackets at the height determined in step 2, approximately 3-4" in from the ends of where the pole will be installed.

Take the back plate off the bracket and place top of plate at marked height. Drill in screws through the top and bottom holes for a secure mount. Repeat this process for all other brackets.

#### 4. Attach Bracket

Take the bracket and screw it onto the installed back plate, turning by hand in a clockwise direction. Turn until tight. Repeat this process with other brackets.

#### 5. Attach Rings and Pole:

Slide rings onto pole. You may want to leave one ring on the outside of each of the end brackets. Set the pole on the brackets. Use Allen key to adjust set screws on the bracket to secure pole.

#### 6. Attach Finials

Attach finials to both ends of the pole.